

ELECTRONIC DISPLAYS INC.

135 S. CHURCH STREET
ADDISON, ILL. 60101
www.electronicdisplays.com



APPENDIX E – PROTOCOL FOR KEYPAD

General:

This program expects to see the Goal entered from the keypad. As counts are received from IN1, the display will show the counts and the difference will be displayed between the top and middle lines.

To set the “Total Shift Goal”:

1. Press the key marked ‘A’ (upper right hand corner).
2. Press the single numeric key representing the address of the scoreboard (factory set to ‘1’).
3. Press the single numeric key ‘1’.
4. Press the one to four numeric keys that represent the number of units desired for this shift (the shift can represent 8 hours, 24 hours, or any other time period that you wish).
5. Press the key labeled ‘D’ (lower right hand corner)

Example:

To set the shift goal to 1200 units, enter the following line:
‘A’ ‘0’ ‘1’ ‘1200’ ‘D’

To preset the “Current Count”:

1. Press the key marked ‘A’(upper right hand corner).
2. Press the single numeric key representing the address of the scoreboard (factory set to ‘0’).
3. Press the single numeric key ‘3’.
4. Press the one to four numeric keys that represent the desired display value.
5. Press the key labeled ‘D’ (lower right hand corner)

Example:

To reset the “Current Count” to zero at the start of a new shift, the key sequence is as follows:
‘A’ ‘0’ ‘3’ ‘0’ ‘D’